

Quick Reference Guide

| | |
|------------------------------------|-----------|
| General Information | 1 |
| Periodic Maintenance | 2 |
| Fuel System (DFI) | 3 |
| Engine Lubrication System | 4 |
| Exhaust System | 5 |
| Engine Top End | 6 |
| Engine Removal/Installation | 7 |
| Engine Bottom End | 8 |
| Cooling and Bilge Systems | 9 |
| Drive System | 10 |
| Pump and Impeller | 11 |
| Steering | 12 |
| Hull/Engine Hood | 13 |
| Electrical System | 14 |
| Storage | 15 |
| Appendix | 16 |

This quick reference guide will assist you in locating a desired topic or procedure.

- Bend the pages back to match the black tab of the desired chapter number with the black tab on the edge at each table of contents page.
- Refer to the sectional table of contents for the exact pages to locate the specific topic required.